



PARTS LIST

Key	Description	Qty. Req.	Part Number	Key	Description	Qty. Red	q. Part Number
1	Seat and Cover, Compact Size	1	29097-1000	17	Set Screw †	1	91084-0320
•	Seat and Cover, Regular Size	i	29127-1000	18	O-ring* †	1	43990-0066
1A	Hinge Only, Compact Size	1	29098-1000	19	Seal* †	1	1040-0000
',	Hinge Only, Regular Size	4	29098-2000	20	Screw †	2	91010-0144
2	Bowl, Compact Size	1	29096-0000	21	Washer, Plastic* †	2	35445-0000
_	Bowl, Regular Size	1	29126-0000	22	Seal Housing †	1	37043-1000
3 & 4	Bowl Spud & Intake Elbow		29048-0000	23	Lock Washer #10, Stainless Steel † 4		
5 W T	& O-ring		23040 0000	24	Screw †	4	91027-0011
5	Hose, 6 feet	1	29035-1031	25	Slinger †	1	6342-0000
3 3	Motor Cover †	1	37042-1000	26	Motors:		
7	Bowl Installation Hardware	4	18753-0637		Motor - 12 Volt †	1	18753-0554
7A	Nut Cap**	4	10755-0057		Motor - 24 Volt †	1	18753-0555
7B	Hex Nut** (Two places)	8		27	Solenoid Valve & Siphon Bro	eaker	
7C	Washer, Stainless Steel**	4			12 Volt	1	37038-1012
7D	Washer, Plastic**	4			Solenoid Valve & Siphon Bro	eaker	
7E	Washer, Starlock**	4			24 Volt	1	37038-1024
7F	Phillips Head Screw**	4		28	Switch Panel	1	37047-2000
8	Bowl O-Ring Seal	4	44101-1000	29	Screw Covers (3/kit)	1	37003-1000
9	Base Assembly**	1	37004-1000		Service Kit		90197-0000
10	1-1/2" Adapter, Discharge Port		98023-0080		Motor & Pump Assembly		
11	Joker Valve* **	4	44106-1000		12 Volt EMC		37072-0092
12	1" Discharge Port**	4	44107-1000		24 Volt EMC		37072-0094
13	Screw** 3		96050-0568				
14	Chopper Plate with Lock Nut †	4	37056-1000	* Dor	to Supplied with Service Kit		
	Macerator Housing †	4	37036-1000		ts Supplied with Service Kit.	000	
15	Centrifugal Impeller t	1	37014-0000	** Parts included with base 37004-1000.			

¹⁶ Centrifugal Impeller † 1 37006-0000 † Parts included in Motor & Pump Assembly.